

DIGGA

AUGER DRIVE

SERVICE KIT

FOR PD25-PD50 DRIVES

INSTRUCTION GUIDE

IN THIS GUIDE:

- ▶▶ The importance of using the correct gearbox oil
- ▶▶ Service intervals & Digga service centres
- ▶▶ What happens when you don't change the oil in your auger drive
- ▶▶ Step by step guide -
How to perform a service
on your auger drive





DO YOU KNOW THE IMPORTANCE OF THE OIL IN YOUR DIGGA DRIVE?

- THE GEAR OIL IN YOUR DRIVE UNIT IS INDEPENDENT OF YOUR MACHINE'S HYDRAULIC SYSTEM.
- OIL FROM YOUR MACHINE DOES NOT LUBRICATE YOUR DRIVE UNIT.

YOUR AUGER DRIVE REQUIRES REGULAR OIL CHANGES TO REMAIN IN ITS OPTIMAL WORKING CONDITION.

DIGGA OIL IS HIGH QUALITY, EXTREME PRESSURE, ISO 320 GRADE MINERAL OIL

STANDARD OPERATING CONDITIONS

First oil change (Service)	Within 3 months OR initial 50 hours of use
Second oil change & subsequent oil change (Service)	After 500 hours of use or 12 months

SEVERE OPERATING CONDITIONS (EXTREME HEAT / CONTINUOUS DRILLING IN HARD GROUND)

First oil change (Service)	Within initial 30 hours of use
Second oil change & subsequent oil change	After 300 hours of use & thereafter



CHANGING OF OIL & REGULAR SERVICING IS CRUCIAL TO THE LONGEVITY OF YOUR AUGER DRIVE

GEAR IN GOOD CONDITION

This is a gear from a drive which has been serviced as per the operators manual and shows very little wear with no more than bedin wear after 10 years of simulated augering.



WORN GEAR

The same drive submitted to the same work load as above over 10 years, with the oil changed only once - at 5 years. While the drive unit shows no decrease in performance, the gear shows visible wear which will deteriorate quickly, leading to total failure.



FAILED GEAR

This drive has never been serviced. The image shows the damage to the gear, which causes total failure of the gearbox.





YOU WILL NEED...

TOOLS & CONSUMABLES

ENSURE YOU HAVE THE CORRECT TOOLS YOU NEED BEFORE YOU BEGIN

Torque wrench
Socket / spanner – 21mm (13/16")
Allen key – 6mm, 8mm, 10mm
Chisel
Dead blow hammer
Scraper / scourer
Wire brush
Screwdriver
Flat metal plate – At least 1" thickness (minimum size of shaft seal)
Lifting strap

CONSUMABLES

Cleaning rags
Loctite 263 high strength thread locker (or equivalent)
Loctite 567 sealant (or equivalent)
Loctite SI 587 flange sealant
Heavy duty grease
Alcohol-based cleaner
Marker - Light colour

PERSONAL PROTECTION (PPE)

Gloves
Safety glasses
Ear plugs

SERVICE KIT CONTENTS (PD25-PD50)

***CHECKLIST**

Instruction Guide
Gear Oil (5L)
Shaft Seal
O-rings
Next Service Sticker



***NOTE** Not all O-rings may be required, depending on your auger drive model.

▶▶ PD25-PD50

GUIDE FOR SQUARE SHAFTS



WHEN SERVICING YOUR DIGGA AUGER DRIVE, YOU WILL BE OPENING UP THE DRIVE UNIT TO INSPECT THE GEARS AND BEARINGS FOR SIGNS OF WEAR & TEAR - IF METAL FRAGMENTS ARE FOUND IN THE SHAFT SEAL, OR THE GEARSET, PLEASE PHONE DIGGA SERVICE FOR ADVICE.



1. Place the drive unit on a stand. Alternatively, with an auger attached, drill a hole into soil and leave the auger in as a stand. Mark a line on the hood and gearbox aligned with the centre of the hoses.



2. Mark the 2 bolts which fasten the hood spacers to the gearset housing (located opposite each other, between the hood and bolts). Do not unbolt these until the motor and gearset are removed - Step 10.



3. Remove the hood bolts with a 13/16 socket or spanner and remove the hood.



4. Clean the motor and gearbox thoroughly to avoid contamination.



WATCH THE STEP-BY-STEP VIDEO
WWW.DIGGA.COM

OR SCAN
THE QR CODE:



DIGGA



5. Continue the alignment mark to match the previous mark at the centre of the motor.



*Take special note of the gear drive-shaft motor spacer sitting on top of the gear drive shaft, or sticking to the motor when lifting. Put it somewhere safe.

6. Remove the motor bolts and motor with a 10mm socket (allen key). If using a rattle gun we recommend using an extension bar.



7. Once the motor has been removed, use an 8mm Allen key to remove the oil bung. Let the oil drain.



8. Remove the gearset.*



9. Remove the ring gear. Use a chisel and hammer to loosen it.



10. Unfasten the last 2 bolts from the gearset assembly housing to release the interim housing and ring gear.



Ensure both spring pins remain on the hood ring gear (evenly spaced). They will help re-align ring gears during assembly.

11. Using a chisel & hammer, remove the interim housing. A pry bar may be required.



12. Remove the sun gear.



13. Remove the gear set. Lifting equipment will be required.



14. Using a chisel & hammer, remove the hood ring gear.



15. Place the housing on a flat surface with the shaft facing up. Remove the seal protector by using a 6mm allen key socket or allen key, to remove the 8mm socket cap screws.



16. Remove the seal protector. You may require a copper hammer to break the seal.



17. With a screwdriver & hammer, remove the seal from inside the seal protector ensuring you do not damage the housing.




18. Remove all (4) O-rings on input housing (motor), output housing, interim housing and ring gear.



19. Clean all parts by using a scraper & scourer or steel brush to remove sealant / contaminants. We recommend using an air gun / air tool to ensure no dirt is left inside the housing.




20. Thoroughly clean down all parts. We recommend using degreaser / alcohol- based cleaner to remove old oil.




21. Before reinstalling the seal, use an alcohol-based cleaner on the seal protector surface (important). Apply Loctite (243 thread locker, medium strength) around the outside of the shaft seal.



22. Position the shaft seal level, with the open side facing up Tap it in evenly using a flat metal plate & hammer.



23. With a pin punch & hammer, gently tap the shaft seal into the seal protector (only hitting the outside wall of the shaft seal) ensuring that you do not damage it.



24. Apply grease to the inside of the shaft seal.



Before replacing the shaft seal protector, ensure the shaft surface is clean and free of any sharp edges. It may damage the new seal when reinstalling.

25. Apply oil-resistant sealant (Flange sealant – Loctite – SI 587) to the output housing surface.



26. Apply Loctite 243 thread locker, medium strength to the seal protector bolts.



27. Replace the shaft seal protector by fastening the 8mm socket cap screws with a 6mm allen key socket or allen key.



28. Apply Loctite 567 thread sealant to the oil bung.




29. Replace the oil bung.



Important:
Too much sealant may damage your drive unit.

30. Place the output housing (with shaft) back on the stand.
Apply a light bead of oil-resistant flange sealant (Loctite SI 587) into the O-ring gauge.



31. Replace with new O-ring.



32. Replace the gearset.



33. Replace the ring-gear. Ensure parts are aligned correctly with previously drawn alignment marks.



34. Apply a light bead of oil-resistant sealant (Flange sealant – Loctite – SI 587) into the O-ring gauge of the interim housing.



35. Replace the O-ring.



36. Place interim housing on the ring gear.



37. Loctite 263 thread locker (high strength) may be used on bolts which hold the hood spacers to the gearset housing.



38. Fasten the hood spacers to the gearset housing by replacing the 2 bolts at the marking points, with a socket or spanner. Torque to 147Nm



39. Apply a light bead of oil-resistant sealant (Flange sealant – Loctite – SI 587) into the O-ring gauge of the interim housing.



40. Replace the interim housing O-ring.



41. Replace the gearset. A soft copper hammer may be used to secure gearset in place.



42. Replace ring gear - Line up previously made marks. Tap down ring gear with a copper hammer as needed. Use the hammer to ensure housing and spring pins are fully inserted.



43. Apply a light bead of oil-resistant sealant (Flange sealant – Loctite – SI 587) into the O-ring gauge of the Motor



44. Replace new O-ring.



45. *Fill to 5mm below the top of the ring gear. Allow time for the oil to settle to the bottom.



46. Apply a light bead of oil-resistant sealant (Flange sealant – Loctite – SI 587) to the drive shaft spacer. Secure it in place (between the motor and gear drive shaft).




47. Replace the motor lining up previously marked alignment lines.



48. Use Loctite 263 Thread locker - high strength on the bolts.



49. Fasten the motor bolts. Torque to 95Nm.



50. Replace the hood. Align the previously marked line with those of marked on the housing.



51. Use Loctite 263 high strength thread locker on the hood bolts.



52. Fasten the hood bolts with a 13/16 socket or spanner. Torque to 147Nm.

DIGGA


WWW.DIGGA.COM



PH: 1300 2 DIGGA
34442

ORDER YOUR NEXT DIGGA SERVICE KIT

SERVICE KIT TYPE	INCLUSIONS	ORDER CODE
PDD-PD5 Kit (Oil Change)	Gear Oil (1L), Oil Change Guide, Next Service Sticker	SER-000056
PD6-PD12 Kit (Oil Change)	Gear Oil (2.5L), Oil Change Guide, Next Service Sticker	SER-000057
PD15-PD50 Kit (Oil Change)	Gear Oil (5L), Oil Change Guide, Next Service Sticker	SER-000061
PDD-PD5 Kit (Service)	Gear Oil (1L), Shaft Seal, O-rings, Service Guide, Next Service Sticker	SER-000082
PD6-PD12 (Service)	Gear Oil (2.5L), Shaft Seal, O-rings, Service Guide, Next Service Sticker	SER-000083
PD15-PD22 (Service)	Gear Oil (5L), Shaft Seal, O-ring, Service Guide, Next Service Sticker	SER-000084
PD25-PD50 (Service)	Gear Oil (5L), Shaft Seal, O-rings, Service Guide, Next Service Sticker	SER-000085



DIGGA SERVICE

YOU CAN BOOK A SERVICE WITH DIGGA AT ONE OF OUR SERVICE CENTRES LOCATED IN BRISBANE, MELBOURNE & SYDNEY. ALTERNATIVELY, PURCHASE A DIGGA DRIVE SERVICE KIT & FOLLOW OUR STEP BY STEP GUIDE.